



INSTRUKCJA MONTAŻU SZAFKI RTV LIGNUM UNO
















Internity
Home


rozmiar	a	b	c
	220	39.4	58cm



Lista elementów:














Ⓐ 	Ⓑ 	Ⓒ 	Ⓓ 
10P ø20	4P ø20	14P ø15*6*28.5	1P ø4*150
Ⓔ 	Ⓕ 	Ⓖ 	Ⓗ 
14P M7*48	4P ø6*18	4P 57*14*20	28P ø8*30
Ⓘ 	Ⓙ 	Ⓚ 	Ⓛ 
12P 15*14*10	20P M3*14	48P M4*14	8P ø35*105
Ⓜ 			
8P M6*12			


Niezbędne narzędzia do złożenia mebla:







Dobrym pomysłem jest użycie miękkiej, ochronnej podkładki podczas montażu.


Lista elementów:

- | | | | |
|-------------------------------------------------------------------------------------|-------------------------------------------------------------------------------------|-------------------------------------------------------------------------------------|-------------------------------------------------------------------------------------|
| ①  | ②  | ③  | ④  |
| 1P | 1P | 1P | 2P |
| 324*375*18 | 324*375*18 | 324*375*18 | 324*375*18 |
| ⑤  | ⑥  | ⑦  | ⑧  |
| 1P | 1P | 1P | 1P |
| 324*392*18 | 324*392*18 | 2200*394*18 | 2176*338*5 |
| ⑨  | ⑩  | ⑪  | ⑫  |
| 1P | 2P | 2P | 1P |
| 501*373*18 | 319*348.5*18 | 319*348.5*18 | 2200*394*18 |
| ⑬  | | | |
| 1P | | | |
| 1900*359*220 | | | |







⑥




⑧




⑦



⑨



10



Internity
Home

Jak dostosować drzwi

